
CNP1 (ANTENNA)
ANT AM
ANT FM
TU1
TUNER UNIT
+8V-FM
+8V-TU
+8V-AM
AM DET
R-CH(AM)
L-CH OUT
R-CH OUT
R-CH(FM)
VT
LO/DX
OSC
IFC-FM
IFC-AM
SEEK
S-METER
SD ST
FM DET
X351
4.32MHz
RDS DEMODULATOR IC351
POWER SW Q351,352
+5V
FM 8V
RV1
S-METER
FM VSM
AM VSM
SD IN
ST IN
MUTE CONTROL Q8
SYSTEM CONTROL
IC301(1/2)
PLL IC1
AM IF
FM REQ
FM IF
AM OSC
FM OSC
LO/DX
PD
X IN
X OUT
X1
7.2MHz
Q2
LPF Q4
LPF SELECT IC2
CR
AM8V
Q3
LO/DX SWITCH Q1
SEEK OUT
AF SEEK
MTL
DOLBY
SIG
TU MUTE
METAL EQ Q101
DOLBY NR IC403
ON/OFF
REC/PB
LIN2
LOUT
RCH
EQ AMP IC402
5620RDS ONLY
RV101 DOLBY LEVEL L-CH
S901 (DIRECTION)
FWD
REV
HP901 PLAYBACK HEAD
FWD-R
REV-L
FWD-L
REV-R
R-CH
PL901 (AMS)
AMS DRIVE Q403,404
AMS CONTROL Q405,406
AMS DETECTOR IC401
AMS OUT
Q407
N/R
TAPE
FF/REW
MO OUT
S903 (TAPE DET)
S902 (MUTE)
M901 (REEL/CAPSTAN)
MOTOR DRIVE Q401,402
LCD
DATA
CLK
CE
INH
LCD DRIVER IC701
S0-56
COM1-3
LCD1 LIQUID CRYSTAL DISPLAY PANEL
NOSE SW
FRONT PANEL DETECT
D711-725
GREEN
AMBER
COLOR SELECT Q702,704
COLOR SELECT Q701,703
PL703 PL704 GREEN
PL701 PL702 AMBER
COLOR
KEY ACK
SW701-718 KEY MATRIX
KEY ACTIVE Q302
KEY ACTIVE Q301
D301
KEY ACT
AD0
AD1
AD2
SYSTEM CONTROL
IC301(2/2)
REF DC
IN14
AM L
FM L
TAPE L
AUDIO SOURCE/ EQ/VOL IC404
INPUT SW
VOLUME
TONE
LOUD
TC01
LINE AMP IC405
FDIN1
FADER
REO1
FNTO1
Q6
Q102
Q103
VCC
1/2 VCC
1/2VCC
+8.5V
DATA
CLK
CE
VOL
REFERENCE DC VOLTAGE IC406
REF DC
D912
D922
ACC MUTE Q907
MUTE CONTROL Q906
D907
ACC
R-CH (BEEP)
CNP6-1
LINE OUT REAR
CNP5
IN(LR)
IN(LF)
LR+
LR-
LF+
LF-
REAR L-CH(+)
REAR L-CH(-)
FRONT L-CH(+)
FRONT L-CH(-)
POWER AMP IC801
AMP ON
MUTE
MUTE
BEEP
AMP ON
AMP MUTE
TUNER ON
FM ON
P ON
MODE2
MODE1
STB
VDD
POWER SUPPLY IC901
VCC
AMP R
ANT R
BATT
AMP.REM
ANT.REM
D923
BU
X302 32.768KHz
X301 8MHz
X1
X0
OSC1
OSC2
RESET
RESET IC902
VDD(1)
VDD(2)
S1 (RESET)
B.U. CHECK
BACK UP DETECT Q903,904
D902
ACC CHECK
ACC DETECT Q908
D908
D909
P.SEL
S301 (POWER SELECT)
ON
OFF
ILL ON
LAMP +B
11V REG Q909
8.5V REG Q910
5V REG Q905
ILL +B
Q901,902 POWER SW
FM 8V
AM 8V
COM 8V
FM
AM
COM

Refer to page 10 for Semiconductor Lead Layouts.




[MAIN BOARD]
IC901
POWER SUPPLY CONTROL
IC902
IC301
SYSTEM CONTROL
IC404
AUDIO SOURCE SELECT EQ VOL CONTROL
IC405
IC406
IC403
DOLBY NR
IC401
IC402
IC351
DEMODULATOR
IC1
IC2
IC901 POWER SUPPLY CONTROL
IC902 PST9329NR
IC301 MN883226R2D SYSTEM CONTROL
IC404 CXA1645Q AUDIO SOURCE SELECT EQ VOL CONTROL
IC405 BA4558F REF DC
IC406 BA4560F BEEP DC
IC403 DOLBY NR
IC401 LA4031 AMS
IC402 BA4560F EQ AMP
IC351 DEMODULATOR
IC1 LC72131 PLL
IC2 TC4W66F (LPF+ANALOG SWITCH)
Q101,102 TAPE SELECT
5620RDS MODEL
AEP MODEL
G MODEL
S-METER
TUNER UNIT
SW BOARD
ANTENNA
TO MD DECK
TO AMPLIFIER BOARD
BU SWITCH
ILL +B SWITCH
LAMP +B RECT.
ACC DETECT
ACC MUTE SWITCH
MUTE ON SWITCH
KEY ACCESS SWITCH
ROS +B SWITCH
MUTE LCH SWITCH
MUTE RCH SWITCH
LO/DX SWITCH
AF-SEEK SWITCH
PL +B SWITCH
MOTOR +B SWITCH
DOLBY LEVEL L-CH
DOLBY LEVEL R-CH
RV201 DOLBY LEVEL L-CH
RV202 DOLBY LEVEL R-CH



Note :

- All capacitors are in μF unless otherwise noted. pF : μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4 W or less unless otherwise specified.
- B+ : B+ Line
- Power voltage is dc 14.4V and fed with regulated dc power supply from BATT and ACC terminals.
- Voltage is dc with respect to ground under no-signal (detuned) conditions.
- no mark: FM
- Voltages are taken with a VOM (Input Impedance 10MΩ). Voltage variations may be noted due to normal production tolerances.
- Signal path.
  ⇨ : FM
  ⇨ : PB